

WARNING

For the writing procedure it is necessary to short-circuit PIN1 with PIN16 of the OBDII socket using the supplied wire in the kit, we suggest access it on the backside of the of the OBD socket by removing the screws and pulling it out away from the kick panel. Then start the writing procedure.

Photo below for reference:



